

## A-Frame Barricade Installation Guide

### Components

- A-Frame (03-AFRAME)
- A-Frame Tube (03-AFRAMET)

### Steps

1. Barricade line must be determined by site inspection, instruction and/or permits
2. Lay two A-Frames down to the distance of the tube and place tube beside
3. Insert tube into the first frame in either the top or middle section of the frame and repeat on the second frame until system can stand on its own
4. Line up the next tube into the corresponding slot on the frame and connect into the following frame
5. Repeat this step until required meterage is covered

### Notes

- The use of two tubes or rails are not required for successful install, this is only required where site deems it necessary for extra stability. One tube or rail is acceptable for installation. If using one rail, it is recommended that this be placed on the top of the frame to ensure better stability.
- The use of the fastening screws is not required to complete install, this is only for the use for extra security and limit the tube from potentially sliding free from the frame

